CP-X30
便攜式藍牙音響

CH

AIWA Electronics International Co., Ltd.
Explore more at www.int-aiwa.com

產品示意圖

CP-X30音響 x1

使用說明書

Type-C 編織充電線 x1

包裝清單

- CP-X30音響 x1
- 使用說明書
- Type-C 編織充電線 x1

產品規格

產品型號：AIWA CP-X30
藍牙版本：V5.4
防水等級：IP67
輸入：5V ⎓ 1A
總額定消耗電功率：300mW
響應頻率：20Hz - 20kHz
電池規格：3.7V / 560 mAh
支持協議：A2DP1.4 / AVCTV1.4 / AVDTP1.3 / AVRCP1.6.2 / HFP 1.8 / SPP 1.2 / RFCOMM1.2 / PNP1.3 / HID1.1.1 / SDP CORE5.4 / 12CAP CORE5.4
藍牙編解碼：AAC / SBC
單體阻抗 / 功率：2Ω / 2W
麥克風靈敏度：-42dB ± 1dB
傳輸距離：10公尺
播放 / 通話時間：6.3小時 (100% 音量) / 16.3小時 (82% 音量)
待機時間：約 400 天
充電時間：約 2 小時
產品重量：62克

產品操作示意圖



① 多功能鍵　② + / - 按鍵　③ 指示燈
④ 麥克風　⑤ Type - C 充電埠

充電狀態指示

指示燈	狀態
紅燈常亮	充電中
白燈常亮	電量充滿
紅燈閃爍	電量過低

產品使用說明

▶ 開機

開機：長按" ▷"多功能鍵 2 秒開機, 紅藍燈長亮 1 秒 。等待連接時紅藍燈交替閃爍, 連接後指示燈滅 。

▶ 關機

關機：長按" ▷"多功能鍵 3 秒關機。

*斷開連接 3 分鐘內無再次連接則自動關機 。

配對方式

1. 打開行動裝置 (手機 / 平板等) 上的藍牙功能 。
2. 長按 " ▷" 多功能鍵 2 秒開機, 並將音響靠近行動裝置 (手機 / 平板等)。
3. 從行動裝置上的設備列表中搜索並連接至"AIWA CP-X30", 音響指示燈燈滅則代表連接成功 。

按鍵說明

▷ x 1	點擊多功能鍵 1 下	播放 / 暫停
━ 1 秒	按下 " ━ " 鍵 1 秒	上一曲
✚ 1 秒	按下 " ✚ " 鍵 1 秒	下一曲
✚ x 1	點擊 " ✚ " 鍵 1 下	增加音量
━ x 1	點擊 " ━ " 鍵 1 下	降低音量

來電管理

▷ x 1	點擊多功能鍵 1 下	接聽 / 掛斷
▷ x 2	點擊多功能鍵 2 下	語音助理
▷ 1 秒	點擊多功能鍵 1 秒	拒接來電

故障排除

▶ 音響無法配對成功

1. 將音響開機後重新開機, 音響會自動配對, 等待連接 。
   *若上述方案無法解決問題, 請依照下方步驟清除配對紀錄
2. 請從行動裝置解除藍牙配對
   音響在開機且未連線至設備時, 連續點按多功能鍵三次後即可清除配對紀錄, 然後等待與行動裝置連接 。

▶ 音響無法連接行動裝置

長按 " ▷ "多功能鍵 2 秒開機, 進入配對模式後將自動連接到最近一次連接的行動裝置 。
若長時間沒有使用後, 再次使用時音響沒有自動連接, 可能需要手動重新連接 。

注意：若音響連線超過 3 分鐘或者配對時間超過 3 分鐘, 音響會自動關機 。

電量與充電

▶ 音響低電量

當音響低電量時, 每分鐘播放一次低電量提示音 , 此時紅燈閃爍, 請盡快為音響充電 。

▶ 低電量自動關機

電量過低時, 音響播放關機提示音, 藍紅燈長亮 1 秒, 並自動關機 。請盡快使用標準充電器為其充電。

▶ 充電燈號

充電時, 指示燈紅燈常亮, 充滿電後白燈常亮, 移除充電設備後白燈熄滅。
充電時間約為 2 小時。

注意：
1. 首次使用前請先確認音響已經充滿電。
2. 請確保給此次電前電池充電, 相關不正電量將導致電池性能衰退。
3. 為最可能延長電池壽命, 至少每 45 天將電池充滿一次直長時間無使用, 請在使用前將電池充電。

限用物質含有情況標示

玫瑰名稱：便攜式藍牙音響
Equipment name
型號（型式）：AIWA CP-X30
Type designation (Type)

單元 Unit	限用物質及其化學符號 Restricted substances and its chemical symbols				
	鉛 Lead (Pb)	汞 Mercury (Hg)	鎘 Cadmium (Cd)	六價鉻 Hexavalent chromium (Cr+6)	多溴聯苯 Polybrominated biphenyls (PBB)	多溴二苯醚 Polybrominated diphenyl ethers (PBDE)
外殼	○	○	○	○	○	○
電路板	○	○	○	○	○	○
喇叭	○	○	○	○	○	○
內部連接線	○	○	○	○	○	○

備考1. "超出0.1 wt %"及"超出0.01 wt %"係指應用物質之百分比含量超出百分比含量基準值。
Note 1: "Exceeding 0.1 wt %" and "exceeding 0.01 wt %" indicate that the percentage content of the restricted substance exceeds the reference percentage value of presence condition.
備考2. "○"係指該應用物質之百分比含量未超出百分比含量基準值。
Note 2: "○" indicates that the percentage content of the restricted substance does not exceed the percentage of reference value of presence.
備考3. "—"係指該應用物質為豁免項目。
Note 3: "The "—" indicates that the restricted substance corresponds to the exemption.

警 語

取得審驗證明之低功率射頻器材，非經核准，公司、商號或使用者均不得擅自變更頻率、加大功率或變更原設計之特性及功能。
低功率射頻器材之使用不得影響飛航安全及干擾合法通信；經發現有干擾現象時，應立即停用，並改善至無干擾時方得繼續使用。
前述合法通信，指無電信管理法規定作業之無線電通信。
低功率射頻器材須忍受合法通信或工業、科學及醫療用電波輻射性電機設備之干擾。

產品保修卡及服務保證書

為保障您的權益，請要求經銷商將店名、店址、購買日期等資料填寫清楚，提供自購買日期起 12 個月之免費保證服務。

- 購買日期填寫不實者，恕無免費服務，對購買日期之認定有爭議時，請出示購買證明(紙本或電子發票)。
- 保證書遺失或購買日期未填寫者，則以出廠日期30天為保固起始日。
- 如需售後服務或有任何疑問，請洽愛華客服中心。
- 服務專線：02-2662-4343 傳真：02-2664-4443
- 愛華網址：https://www.int-aiwa.com/

愛華國際股份有限公司
AIWA ELECTRONICS INTERNATIONAL CO., LTD.

服 務 保 證 書

商　品：
機　型：
主機機號：
購買日期：
姓　名：
電　話：
地　址：
E-mail：
經銷商確認章
（須蓋專業店名、店址、電話）
進口商：中華大雄股份有限公司 電話：02-26624343

委製廠商：愛華國際股份有限公司
進口商：中華大雄股份有限公司
地址：新北市深坑區北深路三段141巷5號
電話：02-2662-4343
商品原產地：中國（CHINA）
製造年份：2024年

CP-X30
Compact Bluetooth Speaker

ENG

AIWA Electronics International Co., Ltd.
Explore more at www.int-aiwa.com

Product Schematic Picture

CP-X30 Speaker x1

User's Manual

Braided Nylon
Type-C Charging Cable

Packing List

- CP-X30 Speaker x1
- Braided Nylon Type-C Charging Cable
- User's Manua

Product Specifications

Model : AIWA CP-X30
BT Version : V5.4
Waterproof Level : IP67
Rated Voltage / Current : 5V / 1A
Rated Power : 300mW
Frequency Response : 20Hz - 20kHz
Battery : 3.7V / 560 mAh
Supported Profiles :
A2DP1.4 / AVCTV1.4 / AVDTP1.3 / AVRCP1.6.2 / HFP 1.8 / SPP 1.2 / RFCOMM1.2 / PNP1.3 / HID1.1.1 / SDP CORE5.4 / 12CAP CORE5.4
Audio Codec : AAC / SBC
Driver Unit Impedance / Power : 2Ω / 2W
Mic Sensitivity : -42dB ± 1dB
Transmission Distance : 10 meters
Working Time : 6.3 hours (@100% Volume) / 16.3 hours (@82% Volume)
Standby Time : About 400 days
Charging Time : About 2 hours
Product Weight : 62g

Schematic diagram of product operation



① Multi-Functional Button　② + / - Button
③ Indicator　④ Microphone　⑤ Type - C Charging Port

Charging Status Indicator

Indicator	Status
Red light on	Being Charged
White light on	Fully Charged
Red light flashes	Low Battery

Product Instructions for Use

▶ Power On

Press and hold the " ▷" multi-functional button for 2 seconds.

Please the speraker is fully charged before the first time using it.

▶ Power Off

Press and hold the " ▷" multi-functional button for 3 seconds.

Connecting to the Product



1. Turn on the Bluetooth (BT) on your mobile device (Phone or Tablet).
2. Turn the speaker on and find "AIWA CP-X30" in the pairable device list, click to connect to the speaker.
3. After connecting to the device, the indicator on the speaker will automatically turns off.

Music Control

▷ x 1	Click the Multi-functional button once	Play / Pause
━ 1 s	Press " ━ " for 1 second	Previous track
✚ 1 s	Press " ✚ " for 1 second	Next track
✚ x 1	Click " ✚ " once	Volume up
━ x 1	Click " ━ " once	Volume down

Call Management

▷ x 1	Click the Multi-functional button once	Answer / Hang up
▷ x 2	Click the Multi-functional button twice	Voice Assistant
▷ 1 s	Press the Multi-functional button for 1 second	Reject Call

Trouble Shooting

▶ Pairing Failed

1. Turn the speaker off and turn it on again. The speaker will automatically enter the pairing mode and waiting for a connection.
   *If the solution above does not work, follow the instruction down below to reset the pairing record.
2. Remove the speaker from your paired list

   When the speaker is powered on and not connected to any device, press the multifunction button three times in succession to clear the pairing record. Then wait to connect with the mobile device.

Speaker Can't Pair with Mobile Device

When the speaker is turned on, it automatically pairs with the last connected device. If it doesn't, you need to connect them manually.

Attention: If the disconnect time or pairing time exceeds 3 minutes, the speaker will automatically power off.

Battery Capcity & Charging

▶ Low Battery Warning

Speaker play a Low battery warning prompt, red light blinks for 1 second. Perform a low power shutdown prompt.
Use a standard charger to charge it.

▶ Low Power Shutdown

Speaker play a power off prompt.
The red and blue indicator would be turned on for 1 second.
Display a low power shutdown prompt.
Use a standard charger to charge it.

▶ Charging Indicator

The red light stays on when the speaker is being charged.
When the speaker is fully charged, the white light stays on.
After unplugging the charger / adapter, the white light turns off.

The charging time is approximately 2 hours.

Attention:

1. Make sure the speaker is fully charged before first use.
2. Ensure you have a full charge for each use, as frequent repeated charging with insufficient power will degrade battery performance.
3. To extend battery life, charge it at least once every 45 days. If you do not use it for a long time, please charge it before use.

E-Manu

AIWA Electronics International Co., Ltd.
Explore more at www.int-aiwa.com